

Stage Plate 73 Mounting Instructions

1. Remove the two Philips screws behind the pitch stick and modulation wheel. Keep these somewhere safe so they don't get lost.



2. Replace the Philips screws with the two thumb screws supplied. Now you're ready to travel!



3. When you get to your gig, remove the thumb screws, place the plate on top of the Stage 2, and replace the thumb screws. Verify the alignment of the plate by making sure it's not touching the mod wheel, then tighten the screws.



4. Place your DB-1 wherever you like on the shelf. You may find it necessary to move the DB-1's rubber feet around for it to nicely straddle the ridge. We've supplied extras for this purpose.



 **Ocean Beach Digital**
4876 Santa Monica Ave #162
San Diego CA 92107
864-372-9227
www.oceanbeachdigital.com